


- F1 = Fuse 220V 0.5AF
- S1 = Switch 220V 1A
- S2 = Switch 220V 1A
- TR1 = Transformer 220V pri 1A
24V sec
- D1 = B250CA500 = BY179
- D2 - D5 = 1N4002
- C1 = 4700µF 50V
- C2 = 0,33µF
- C3 = 0,1µF



Rel_{1,2} = Relais DIL 24V DC
2 changers

J_{1,2} = 6.3mm insulated Jade mono
 J₃ = 6.3mm insulated Jade stereo
 J₄ = 11Pin Leslie Jack

HAMMOND XK30 to Echolette ME 115
 or Dynacord DC100 INTERFACE

MS 2008